

Receiver light

Flite Controller meaning



Light blue solid

Ready to ride



Red flashing

Alert (high temp, tilt, overcurrent, system error)



Blue flashing

Armed



Blue chasing

Motor running



Orange flashing

Disconnected Flitecell / Controller



Orange chasing

Searching for new pair Flitecell / Controller



Purple solid

Flite App connected



Purple chasing

Flite App data transfer